

One Man's Advice on the Determination of Dissolved Oxygen in Seawater

Lou Codispoti

April 1988

Introduction


With the exception of salinity determinations, dissolved oxygen is probably the most commonly measured chemical oceanographic variable. Usually, dissolved oxygen is determined by some modification of the classic Winkler (1888) method.

Range of Oceanic Dissolved Oxygen Concentrations


Dissolved oxygen concentrations are generally expressed in millimolar, $\mu\text{Moles/kg}$, mg-atoms/liter or ml/liter (mg-atoms of O_2 /liter = $0.08931 \times \text{ml/liter}$). Values from 0 to $>13 \text{ ml/liter}$ are encountered in the ocean. The equilibrium solubility values for dissolved oxygen increase with decreasing temperature, and salinity, and they range from about 4 to 9 ml/liter throughout most of the ocean. Generally, biological processes are responsible for the wide range of values which are encountered. Phytoplankton growth, for example, can cause oxygen supersaturations while respiratory processes can remove all of the oxygen originally present in some water masses.

Chemistry of the Winkler Method

Manganous sulfate (or chloride) solution is added to a known quantity of seawater and is immediately followed by the addition of an alkaline sodium hydroxide-sodium iodide solution. Manganous hydroxide precipitates and reacts with the dissolved oxygen in the water with the formation of a hydrated tetravalent oxide of manganese.



Upon acidification, the manganese hydroxides dissolve. In the acid solution, the tetravalent manganese in $\text{MnO}(\text{OH})_2$ acts as an oxidizing agent and liberates free iodine from the iodide ions.



2. Air Oxidation of Iodide. Iodide reacts with oxygen in acidic solution:



To minimize this source of error, the optimum pH to permit the proper reaction between thiosulfate and iodine and prevent the above reaction was determined. The optimum pH range was found to be 2.0-2.5 and the reagent concentrations were adjusted to attain a final pH in the appropriate range.

3. Improper Blank Determinations. In most previous methods, allowance was made only for positive blanks, but negative blanks caused by reducing impurities are also possible. Consequently, a method for determining positive and negative blanks was devised. This procedure will be described below.
4. Improper Standards. It was found that potassium dichromate, which had been used in some methods, was not a suitable standard. The best standard is potassium iodate, but potassium biiodate can also be used if it is dried by vacuum dessication. Potassium iodate can be dried in an oven at ~110°C.

Comparison experiments indicate that the error introduced by not using the glassware necessary to eliminate transfers is less than 0.05 ml/liter if aliquots are drawn with care and the Carpenter reagents are employed.

Preparation of Reagents

Reagent Bottles. The reagent bottles used for the manganous sulfate (or chloride), potassium hydroxide-iodide, and sulfuric acid should be such that automatic filling of the pipets is possible. In order to prevent photochemical reactions, the alkaline iodide reagent bottles should be of brown glass or else the exterior painted black.

Manganous Chloride. Dissolve 600 g of reagent grade $\text{MnCl}_2 \cdot 4\text{H}_2\text{O}$ in distilled water. Adjust final volume to 1 liter. Manganous sulfate may be substituted for the chloride, but the chloride is suggested because of its solubility and its freedom from higher valence manganese compounds. When substituting manganous sulfate on a form of MnCl_2 with more or fewer waters of hydration than in $\text{MnCl}_2 \cdot 4\text{H}_2\text{O}$, adjust for differences in formula weight.

Alkaline Sodium Iodide. Dissolve 320 g of reagent grade NaOH and 600 g of reagent grade NaI in distilled water. Dilute to 1 liter.

Sulfuric Acid. Make up 280 ml of concentrated reagent grade H_2SO_4 to 1 liter with distilled water. *Use caution, as a great deal of heat is liberated!*

Starch Solution. Dissolve 1-2 g of starch indicator in 100 ml of distilled water, or boil a similar amount of potato starch in distilled water for about 5 minutes. The indicator should be made up fresh every day if possible since bacterial action degrades it. One sign of a degraded indicator is a reddish tinge to the normally blue color. It is permissible to "play around" with the starch concentration a bit to produce an indicator color intensity that meets your personal preferences!

Sodium Thiosulfate Solution. Dissolve 1.6 g for the Aliquot method (see below) or 35 g (for the Carpenter method) of reagent grade $\text{Na}_2\text{S}_2\text{O}_3 \cdot 5\text{H}_2\text{O}$ in 1 liter of distilled water. Add 1 pellet of NaOH and 2 drops of chloroform. Let stand (preferably for a few days) before using.

NOTES:

a. The sodium hydroxide is added to negate the influence of any dissolved CO_2 as the presence of carbonic acid causes the following reaction:



b. Sodium thiosulfate is degraded by the action of bacteria. Chloroform is added to prevent bacterial growth.

Primary Standard. Dissolve 0.3567 g of oven dried ($\sim 105\text{-}110^\circ\text{C}$) KIO_3 or 0.3250 g of $\text{KH}(\text{IO}_3)$ dried in a vacuum desiccator in distilled water. Make up to exactly 1 liter. This solution is 0.01000 N.


NOTE:

KIO_3 is preferred because of its stability during drying. $\text{KH}(\text{IO}_3)_2$ (BI-IODATE) decomposes at temperatures above $\sim 100^\circ\text{C}$.

Standardization of the Thiosulfate

The thiosulfate solution should be standardized under the same conditions as the actual procedure for the determination of dissolved oxygen. By so doing, possible errors are compensated. The best practice is to run standards and blanks before and after every sample run until you are *sure* that the interval between standard runs can be extended.

To about 40 ml of distilled water add 1 ml of the H_2SO_4 reagent. Mix thoroughly. Add 1 ml of the NaOH•NaI solution. Mix and wash down the sides of the flask thoroughly. The solution should be distinctly acid, clear and colorless. If any basic microenvironments exist at this point due to insufficient washing of the reagents into the bottle and insufficient stirring, you will obtain poor results. Make good use of your wash bottle and stirring motion before going on! Add 1 ml MnCl_2 reagent and, after mixing, pipet into the flask 10 ml of the standard (BI) iodate solution. Stir for ~ 5 sec. Then titrate with thiosulfate in the same manner described below for samples.



$$\frac{10 \text{ ml } \text{KIO}_3 \times 0.0100 \text{ N}}{[\text{ml } \text{Na}_2\text{S}_2\text{O}_3 - \text{B}]} = \text{Normality of } \text{Na}_2\text{S}_2\text{O}_3$$

where 0.01000 is the normality of the iodate solution, and B = Blank. Often, it is preferable to weigh out standards that are not exactly 0.01000 N because striving for an exact weight takes

extra time and tends to make the weighing process less exact. It is, of course, a simple matter to substitute a different normality when performing your calculations.

Blank Determination. This procedure is the same as the standardization procedure except

that exactly 1 ml of the standard KIO_3 is added instead of 10 ml, and, after the first titration, another 1 ml of standard is added and the solution is titrated again. The blank is equal to the ml of thiosulfate needed for the first titration minus the ml of thiosulfate needed for the second titration. The blank may be either positive or negative.

(For surface and near-surface DO sampling from small boats, perhaps a 3-fold DO sampler bucket could be used [refer to following]?)

Sample Collection and Treatment

Samples for the determination of dissolved oxygen should be taken from the water sampling bottle immediately upon its arrival on deck. The sample should be collected in a calibrated, ground glass-stoppered container. Two types may be used—bottles approximating 250 ml and bottles approximating 125 ml. In the case of the latter, the entire contents of the flask is eventually used for titration while with the former, an aliquot is taken. We generally use 125 ml (approx.) clear glass bottles that are calibrated to contain with an accuracy of ± 0.04 ml and titrate the entire bottle as suggested by Carpenter (1965).

To fill the oxygen bottle from the oceanographic sampling bottle (e.g., a Niskin bottle), you will need a length of amber surgical tubing (or similar material) with an inside diameter of approximately 1/4". The length of this tubing should be approximately 12", but keep the length as short as you can without sacrificing ease of movement while filling the oxygen bottle. To one end of this tubing attach a length of stiff plastic tubing or glass tubing that is a bit longer than the oxygen bottle. You are now ready to begin the challenging task of drawing a high quality oxygen sample without contamination while bathed in an atmosphere that is about 21% oxygen!! Believe it or not, it can be done, and with a bit of practice you can do it!

A method that I have used will be described next, but remember the principle, which is to minimize contact of the seawater sample with the atmosphere. With this basic principle in mind, you can modify my technique to fit your particular blend of motor skills. When I draw an oxygen sample, I proceed as follows:

- 1) Attach the soft tubing to the spigot of the Niskin (or other type of bottle), and open the air vent on the Niskin bottle.
- 2) Open the spigot valve and flush the sampling tubing so that all air bubbles are removed. I find that the easiest way to do this is to hold the tubing in a straight line (more or less) and point the tubing downward while letting water flow through the tubing at maximum velocity for a brief period. At this point, you control the velocity of flow by pinching the soft tubing with your fingers. If the tubing is not completely free of bubbles after the first brief period of maximum velocity, repeat the process one or more times by turning the flow on and off by pinching and unpinching the rubber tubing. Some investigators prefer to try to remove the bubbles from the tubing by holding it in a U-shape with the open end up and letting the water flow gently through the tubing. Any method or combination of methods that removes all of the bubbles from the tubing is OK.

3) The next step is to rinse your oxygen bottle while minimizing contact with the atmosphere. I do it by allowing the water to flow at a moderate pace out of the bubble-free tubing, inserting the tubing so that the stiff portion touches the bottom of the bottle, and then inverting the bottle. While in the inverted position, I move the stiff part of the tubing around so that a moderate "sheet flow" rinses the entire bottle with minimal turbulence.

4) Next, I momentarily stop the flow by pinching the tubing and invert the bottle quickly. Then I start a moderate flow again and let the bottle fill as quickly as possible without forming a lot of turbulence while keeping the stiff part of the tubing near the bottom of the bottle. As the bottle begins to overflow, I let the overflow water rinse the ground glass stopper. After about half a bottle volume has overflowed, I begin to withdraw the tubing from the bottle by steadily raising while allowing another bottle volume (approx.) to overflow and continue to rinse the stopper.

5) Now I immediately add 1 ml of the manganous reagent by placing the tip of the delivery pipet just below the surface of the sample in the oxygen bottle. This step is immediately followed by the addition (in like manner) of the alkaline-iodide reagent. Both reagents are very much denser than seawater, and they sink to the bottom and displace the upper 2 ml of seawater in the bottle, which is helpful since the upper water has been in contact with the atmosphere. It is best not to immerse more than about 1/8" of the tips of the delivery pipets since this should help to cut down on contamination. Not immersing the tips at all increases the possibility of contamination from the atmosphere.

6) Now place the stopper in the bottle without trapping bubbles. I have found that the easiest way is also the way that works the best. Just drop the stopper into the bottle from a height of about one inch! If you place the stopper in the bottle slowly and carefully, you are more likely to trap a bubble. The stopper displaces the upper few ml of liquid in the neck of the bottle, thereby removing most of the atmospheric contamination that may have accumulated.

7) Now push down on the stopper to make sure that it is tight, and closely inspect the bottle to make sure that it is free of bubbles. A bubble the size of a pencil eraser will completely invalidate any sample, and much smaller bubbles can also totally ruin a sample depending on ambient concentrations and the accuracy that you desire. The best rule of thumb is to start over again if you can see a bubble in your sample even though there exist exceptional situations in which heating or the addition of the first two reagents can cause bubbles to form within the sample.

8) Now invert the bottle several times to mix the first two reagents with the sample. A precipitate will form. Allow the precipitate to settle, and repeat the mixing process one time. Generally, you should wait at least 15 minutes before repeating this mixing process. If you are using the Carpenter method (which we prefer), your sampling bottle will be a calibrated (for volume) bottle made out of clear glass. Because of the possibility of undesirable photochemical reactions, it is important that you keep the bottle in the dark as much as possible. We accomplish this by placing the bottles in a carrying case (which is painted black on the inside) in between manipulations. Also try to keep the samples cool (i.e., in the shade).

9) The next step is to add the acidic reagent. Some prefer to do this immediately after the precipitate in the oxygen bottle has settled for the second time, and others prefer to do it just before beginning the oxygen titration. I have uncovered no convincing evidence that favors one technique over the other, but I prefer to add the acid fairly soon after the second settling and have had good success with this approach. In the Carpenter version of the Winkler method, the reagents are adjusted so that the final pH is between 2 and 2.5.

This range of pH minimizes unwanted side reactions but is just barely acid enough to dissolve the precipitate. If the precipitate is not completely dissolved when you are about to start your titration, just add another drop of acid.

NOTES:

a. Occasionally after the addition of sulfuric acid, a gas bubble will appear. This bubble is composed largely of carbon dioxide and a little nitrogen which may have been liberated from the solution. The former results from the chemical reaction of the acid and carbonates. The presence of the nitrogen is accounted for by the reduced solubility of this gas upon the addition in electrolytes of the reagents and the possible increased temperature of the sample.

b. In running determinations of dissolved oxygen on fresh or slightly brackish waters, considerable difficulty may be experienced in obtaining complete solution of precipitate. However, solution may readily be affected by the addition of a few crystals of sodium chloride to the acid solution.

c. In limnological studies, the use of hydrochloric acid may be substituted for the sulfuric acid. (Concentrated HCL is 12N and concentrated H₂SO₄ is 36N.)

Titration of Samples

If an aliquot of sample is drawn from a ~250 ml brown glass bottle, the buret used for measuring the quantity of standard sodium thiosulfate solution should deliver 25 ml and be graduated to 0.05 ml. Readings of the buret should be made to 0.01 ml. If a large number of samples are to be titrated, it is a marked convenience to have an arrangement so that the buret may be filled by gravity with an automatic adjustment to the zero point.

If an aliquot of the sample is taken for titration, a measured volume of 100 ml is titrated in an Erlenmeyer flask with a standardized thiosulfate solution introduced from the buret. About 1 ml of the starch indicator solution is added and the solution titrated until the blue starch-iodine color disappears. When the blue color just disappears, read the buret. The starch is generally not introduced until the solution is a fairly pale yellow which means about 1/2 to 2/3 of the way through the titration for most samples. When samples are taken from low oxygen zones they will, however, be a pale yellow color at the beginning of the titration.

We have seen no compelling evidence to suggest any differences due to the point at which the starch is introduced *as long as it is before the end point!*

It is difficult to describe how to detect the end-point on the printed page, and my advice is to try to have an experienced analyst demonstrate this for you. In case you cannot find an experienced and competent analyst, here is a method that should work. 1) As the blue color begins to disappear, start to add the thiosulfate in small increments and begin to record the buret readings. 2) If your eyes are like mine, you will not see too much color change near the end-point. Instead, the solution will become progressively clearer and/or brighter. 3) Keep on adding thiosulfate until you no longer see changes in clarity and/or brightness upon the addition of more thiosulfate. 4) The reading that corresponds to the last thiosulfate addition that caused a visible change is the end-point! 5) Do not allow your desire to obtain the best end-point cause the titration to take too much time! See note (b) below.

With the Aliquot method, the dissolved oxygen concentration is calculated from the following equation:

Folding an ordinary sheet of white paper in half and placing the bottle on the lower half sitting on the stirrer with the upper half serving as a background helps detect the endpoint.

$$DO = \frac{[R - R_{\text{blk}}] V_{\text{IO}_3} \cdot N_{\text{IO}_3} \cdot E}{[R_{\text{std}} - R_{\text{blk}}] \left[V_s - V_{\text{reg}} \cdot \frac{V_s}{V_b} \right]} - DO_{\text{reg}} \cdot \frac{125 \text{ ml}}{V_b}$$

where

DO = dissolved oxygen (ml/liter)

R = sample titration buret reading

R_{blk} = difference between blank titration buret readings (i.e., the blank value)

R_{std} = standardization buret reading

V_{IO_3} = volume of primary standard (ml)

V_b = volume of sample bottle (ml)

V_s = volume of titration aliquot (ml)

V_{reg} = volume of sample displaced by reagents (2 ml for this method)

N_{IO_3} = normality of primary standard

E = 5,598 ml O_2 /equivalent

DO_{reg} = 0.018 ml/liter, the amount of oxygen added with the reagents if you were using the 125 ml flasks recommended by Carpenter (1965b).

NOTES:

a. Since the precipitate containing the dissolved oxygen has settled before the addition of the H_2SO_4 , only 2 ml of sample are displaced by reagent additions.

b. After completing the titration, if the solution is permitted to stand for a short period of time, the blue starch-iodine color may again become evident. *This should be ignored.* but, in general, titrations should be carried out as quickly as possible consistent with accuracy.

If the entire sample is to be titrated, the amount of dissolved oxygen may be calculated from the following equation which applies to the "no-transfer" Carpenter method that we prefer.

$$DO = \frac{[R - R_{\text{blk}}] V_{\text{IO}_3} \cdot N_{\text{IO}_3} \cdot E}{[R_{\text{std}} - R_{\text{blk}}] [V_b - V_{\text{reg}}]} - DO_{\text{reg}}$$

where

- DO = dissolved oxygen (ml/liter)
- R = sample titration buret reading
- R_{blk} = blank correction factor
- R_{std} = standardization buret reading
- V_{IO₃} = volume of KIO₃ standard
- V_b = volume of sample bottle (ml)
- V_{reg} = volume of sample displaced by reagents (ml)
- N_{IO₃} = normality of KIO₃ standard (equivalents/liter)
- E = 5,598 ml O₂/equivalent, and
- DO_{reg} = oxygen added with reagents

For the procedure described,

$$DO = \frac{[R - R_{\text{blk}}] 559.8}{[R_{\text{std}} - R_{\text{blk}}] V_b - 2} - 0.018$$

NOTE:

Another advantage of the no-transfer method is that the bottles can be calibrated for volume with high accuracy ($\pm 0.03\%$). This is a much higher accuracy than is likely to be obtained when drawing aliquots in the field.

Sources of Error in the Winkler Determination Caused by Substances Found Only Occasionally in Seawater

a. If nitrites are present in large quantities, high values for oxygen may be obtained because of the following chemical reaction:



With the exception of oxygen deficient regions where O_2 is less than ~ 0.1 ml/l, the concentrations of nitrites in seawater are usually so small that any error introduced by their presence is negligible.

b. If hydrogen sulfide is present, the Winkler method for determining oxygen is not applicable. Hydrogen sulfide will react with the dissolved oxygen and with iodine. For example, one possible reaction is:



The sulfur formed is almost colloidal in nature and such waters will be devoid of oxygen, except for the possibility of an interface zone where $\text{O}_2 + \text{H}_2\text{S}$ may be present.

The hydrogen sulfide reacts with iodine and if present in sufficient quantities may be determined iodometrically.

c. In waters polluted by industrial waste or containing relatively large concentrations of reducing material, Winkler's method is not applicable because any iodine liberated may react with the reducing substances.

Low Concentration Dissolved Oxygen Method

Broenkow and Cline (1969) have described a colorimetric dissolved oxygen method which is more suited to low concentrations (< 0.4 ml/liter) than the more normal methods described above. The normal Winkler methods described above cannot resolve the 0 to ~ 0.15 ml/l dissolved oxygen range, and high nitrite levels often occur in low oxygen waters.

Automated Methods

A number of investigators (Williams and Jenkinson, 1982; Friederich, Sherman and Codispoti, 1984; Culberson and Huang, 1987) have recently automated the dissolved oxygen titration. These methods reduce eye-strain, improve precision, and allow the data to be directly acquired by computer. They do not require the addition of starch, since the yellow iodine color that is poorly perceived by the human eye can be detected with great precision electronically.

REFERENCES

- Broenkow, W.W. and J.D. Cline. 1969. Colorimetric determination of dissolved oxygen at low concentration. *Limnology and Oceanography* **14**: 450-454.
- Carpenter, J.H. 1965a. The accuracy of the Winkler method for dissolved oxygen. *Limnology and Oceanography* **10**: 135-140.
- Carpenter, J.H. 1965b. The Chesapeake Bay Institute technique for the Winkler dissolved oxygen method. *Limnology and Oceanography* **10**: 141-143.
- Carpenter, J.H. 1966. New measurements of oxygen solubility in pure and natural waters. *Limnology and Oceanography* **11**: 264-277.
- Carritt, D.E. and J.H. Carpenter. 1966. Comparison and evaluation of currently employed modifications of the Winkler method for determining dissolved oxygen in seawater; a NASCO report. *Journal of Marine Research* **24**: 286-318.
- Culberson, G.H. and S. Huang. 1987. Automated Amperometric Oxygen titration. *Deep-Sea Research* **34**: 875-880.
- Friederich, G.E., P. Sherman and L.A. Codisoti. 1984. A high precision automated Winkler titration system based on an HP-85 computer, a single colorimeter and an inexpensive electro-mechanical buret. Bigelow Laboratory for Ocean Sciences Technical Report 42, 24 pp.
- Hydrographic Office. 1968. Instruction manual for obtaining oceanographic data. 3rd edition. *U.S. Hydrographic Office Publication 607*.
- Murray, C.N. and J.P. Riley. 1969. The solubility of gases in distilled water and sea water—II. Oxygen. *Deep-Sea Research* **16**: 311-320.
- Williams, P.J. LeB. and N.W. Jenkinson. 1982. A transportable microprocessor-controlled precise Winkler titration suitable for field station and shipboard use. *Limnology and Oceanography* **27**: 576-584.
- Winkler, L.S. 1888. The determination of dissolved oxygen. *Ber. Dtsche. Chem. Ges.* **21**: 2843-2855.
- Wust, G. 1964. Stratification and circulation in the Antilleon-Caribbean basins. Columbia University Press, London and New York, 201 p.

THE ACCURACY OF THE WINKLER METHOD FOR DISSOLVED OXYGEN ANALYSIS¹

James H. Carpenter

Department of Oceanography, The Johns Hopkins University, Baltimore, Maryland

ABSTRACT

The potential errors in the various techniques for the Winkler method have been examined and a new technique developed. The accuracy of this technique has been tested by comparison with standards based on dissolving known quantities of oxygen in oxygen-free water. An accuracy of 0.1% was observed, so the technique appears suitable for oxygen analyses requiring an accuracy of greater than the 3-5% observed with the common techniques.

INTRODUCTION

The Winkler method of analysis for oxygen dissolved in water is unusual in that the result is not based on oxygen as a standard. Studies of the accuracy of the method have been based on comparison with the results of another method. Extraction and gasometric measurement has been the alternate method in a number of studies since Winkler proposed the method in 1888. The most recent example of this approach is the work of Wheatland and Smith (1955), in which the accuracy of the titrimetric technique used in the solubility studies of Truesdale, Downing, and Lowden (1955) was considered. The results appeared to be valid, and the solubility values were suggested for application to oceanographic (Richards and Corwin 1956) and limnological (Mortimer 1956) research. Solubility measurements by Klots and Benson (1963), as well as others, do not confirm the Truesdale, Downing, and Lowden results and, therefore, suggest significant errors in their techniques.

Discordant results of comparisons of techniques during International Geophysical Year oceanographic expeditions have led to a question of the accuracy of several techniques and to the rejection of the oxygen analyses in preparing summary charts of station data. Differences between nominally analogous procedures have also been

observed in an intercomparison experiment conducted by the chemical methods subcommittee of the National Academy of Sciences Committee on Oceanography. Results and conclusions from this experiment will shortly be published as a NASCO report (D. E. Carritt, personal communication).

In view of the discrepancies in the solubility measurements and in the techniques used on oceanographic expeditions, and as a first step in the determination of the solubility of oxygen in pure water and seawater, the accuracy of a technique for the Winkler method is evaluated here so that the reliability of the analytical results can be estimated. The experimentally simpler and logically more straightforward operation of dissolving known quantities of oxygen in oxygen-free water was chosen to produce a primary standard.

The sources of error in the manipulations required for the Winkler method for analyses of oxygen dissolved in pure water were considered to be the following:

- 1) Air oxidation of iodide.
- 2) Volatilization of iodine.
- 3) Oxygen contributed by the reagent solution.
- 4) Iodate contamination of the iodide solutions.
- 5) Consumption or production of iodine by reagent contaminants.
- 6) Difference between titration end point and the equivalence point.

These possible errors were examined individually and conditions found under which all were negligible except oxygen

¹ Contribution number 76 from the Chesapeake Bay Institute and the Department of Oceanography, The Johns Hopkins University. This work was supported by the National Institutes of Health through Grant RG-5982.

contributed by the reagent solutions. As a result of these tests, the following procedure was considered to have minimum errors and was tested for accuracy.

METHODS AND MATERIALS

Technique for the Winkler method

Reagents—The first two errors can be reduced by the use of the following reagents:

MnCl ₂ ·4H ₂ O	600 g/liter	6 ml/liter of sample
NaI	600 g/liter	} 6 ml/liter of sample
NaOH	320 g/liter	
H ₂ SO ₄	500 ml/liter	3.6 ml/liter of sample

Air oxidation is minimized by a final pH of 2.

Volatilization—Loss of iodine during exposure of iodine solutions to the atmosphere is minimized by the formation of the triiodide complex with the high iodide concentrations produced by these reagents. However, a more reliable system was based on elimination of transfer of the sample until most of the iodine had been reduced with thiosulfate.

Reagent blanks—The errors produced by iodate contamination and reagent contamination were serious but could be reduced by careful selection of chemicals. Whereas iodate contamination is commonly recognized, reducing impurities in the reagents were the major sources of a negative blank. An example of this blank is shown in Table 1. The negative values make six or more titrations necessary for precise standardiza-

tion of the thiosulfate solution. The data in Table 1 could indicate either an end-point error or a negative reagent blank.

The association of the negative blank with the reagents was shown by the following kinds of experiments. Repeated photometric titrations of iodine (from iodate) and thiosulfate were performed using syringe microburettes to add less than 10 microequivalents of either substance to the 200 ml of solution containing the reagents, that is, adding iodine and titrating it with thiosulfate was followed photometrically several times in the same solution. The first titration was invariably different from the successive ones in that less thiosulfate was required to reduce the iodine in the first titration than subsequently.

A second demonstration that the negative blank is associated with the reagents was the performance of titrations with different quantities of reagents present and with suitable quantities of iodine so that least squares regression analysis could be used.

0.5-ml reagents:	Thiosulfate = -0.011 + 68.1 iodine
1.0-ml reagents:	Thiosulfate = -0.029 + 68.76 iodine
2.0-ml reagents:	Thiosulfate = -0.059 + 68.90 iodine

The dependence of the intercept on the quantity of reagent is clear. The lack of consistency in the slope reflects the volumetric errors with the microsyringe burette, since less than 10 microequivalents (μeq) of iodine were used. The results clearly show a loss of iodine associated with the initial solution rather than a systematic difference between the equivalence point and end point.

The source of the reducing impurity was found in the sodium iodide. Examination of sodium iodide from several sources has shown a variation of two orders of magnitude in the value of the blank. The blank from the sodium iodide may be reduced to negligible levels by removing dark and discolored particles by hand using tweezers and a hand lens.

End-point detection—The end-point de-

TABLE 1. *Iodine titrations for blank and precision estimate*

Iodine taken (meq)	Thiosulfate solution (g)	Thiosulfate solution (calculated) (g)	Difference (g)
0.08824	6.127	6.125	+0.002
0.09864	6.850	6.851	-0.001
0.10432	7.247	7.248	-0.001
0.13836	9.624	9.625	-0.001
0.15119	10.516	10.520	-0.004
0.19976	13.912	13.912	0.000
0.20084	13.993	13.988	+0.005

Least squares fit:
 Thiosulfate (g) = -0.037 + 69.83 iodine (meq)
 Standard error of estimate 0.003 g

tection by visual indication with starch and by amperometric and potentiometric measurements has been studied by Knowles and Lowden (1953). Colorimetric determination with starch and amperometric measurement were compared in the study of the iodine-thiosulfate reaction of Bradbury and Hambly (1952). Both these studies showed that the starch-indicated end point is significantly different from the equivalence point in titrations of iodine solutions at concentrations corresponding to air-saturated water. The authors recommended the amperometric technique but remarked on the variable sensitivity of the electrodes.

Since triiodide ion is the most abundant species of iodine present in the solution, particularly near the end point, determination of triiodide ion was expected to be a superior method of end-point detection. Triiodide ion strongly absorbs near-ultraviolet light with maximum absorption at 350 m μ . Photometric titration is relatively simple and free from the erratic behavior of electrodes. The sensitivities of the several iodine end-point techniques, as found by Bradbury and Hambly (1952) and during this work, are as follows:

Visual starch	10 μ eq/liter
Colorimetric starch	2 μ eq/liter
Amperometric technique	(0.02) μ eq/liter calculated free iodine
	0.08 μ eq/liter in 0.01 N iodide
Ultraviolet absorption	0.015 μ eq/liter in 0.01 N iodide

Titration procedure—A sample was placed in a 500-ml Pyrex bottle with rounded stopper and the reagents added with syringes. A 100-ml portion of the resulting solution was removed with a pipette calibrated "to contain." Thiosulfate solution was added to the bottle contents from a weight burette to nearly complete reaction (very light straw color). A 200-ml aliquot of the reaction mixture was transferred to the photometric titration apparatus, which consisted of a Beckman Model DU spectrophotometer with a modified cell compartment to accommodate a 200-ml Florence flask and a reference air path con-

structed with four mirrors mounted on a modified cell carriage. The contents of the Florence flask were stirred with a magnetic stirrer and thiosulfate solution added with a 1-ml syringe microburette until the optical density was approximately 0.2. Increments of 0.01 ml thiosulfate solution were added and the end point found from a plot of optical density vs. added thiosulfate. The precision of the technique is 0.003 g thiosulfate solution (Table 1).

Standardization of thiosulfate—Iodine generated from biiodate, iodate, or dichromate is commonly used to standardize thiosulfate solutions. Potassium dichromate is not suitable as a standard for millinormal solutions, since the air oxidation error is difficult to avoid at the high acidities required. Even with the precautions of generation of iodine under a nitrogen atmosphere and adjustment of the pH to 3 before titration, intercomparison of assayed (better than 0.1%) potassium dichromate and potassium biiodate (G. Frederick Smith Co., Columbus, Ohio) gave differences of 0.5%.

Either potassium iodate or potassium biiodate appears to be suitable as an iodine standard. However, the iodate is easier to dry and might be expected to be more reliable. Comparison of potassium biiodate (G. Frederick Smith Co.), which had been dried over magnesium perchlorate and had a stated assay of 100.01%, with potassium iodate (Mallinkrodt), dried at 180C and certified as 100.05–99.95%, gave agreement to 0.04%.

Preparation of dissolved oxygen solutions

The apparatus shown in Fig. 1 was used to prepare solutions of known oxygen content. Two high-vacuum three-way stopcocks were joined to form a central chamber (4.7 ml) with four entrances. The 1-liter bulb shown at the top permitted vigorous boiling under vacuum. The Teflon plunger syringe was filled with mercury and degassed under high vacuum before assembly of the apparatus. Fig. 1 shows the apparatus during the removal of dissolved gases from the water.

PROCEDURE

1) The apparatus was filled with 700 ml of water and partially immersed in a water bath that covered the lower half of the bottle. A combination electric heater and magnetic stirrer was used to boil the sample water at 55C under low (aspirator) vacuum with stirring for 45 min. Repeated tests showed that no detectable oxygen remained after 15 min.

2) The apparatus was allowed to cool to ambient temperature in the water bath during a 4-hr period after the upper bulb was filled with nitrogen freed from oxygen by scrubbing with vanadous sulfate solution.

3) The lower stopcock was rotated to isolate a known quantity of water in the bottle and stopcock, and the upper bulb was removed.

4) The central chamber was freed of all water by draining and drying under high vacuum at room temperature while flushing with dried air.

5) A glass tube containing a 20–30C thermometer with insulation around the lower portion containing the thermometer bulb was attached to the upper ball joint. The other end of this tube led to a soap bubble flowmeter. A supply of high-purity oxygen gas was attached to the lower ball joint so that gas could flow through the central chamber and out around the thermometer to the flowmeter.

6) The oxygen gas was passed through the central chamber for 5 min at 100 ml/min. The gas temperature was measured, the gas flow stopped, and the barometric pressure noted. Both stopcocks were then turned to isolate a known quantity of oxygen.

7) The thermometer and oxygen supply were removed, the magnetic stirring bar was retained in the bottle bottom with an auxiliary magnet, and the apparatus inverted and clamped so that the magnetic stirring bar could be operated with a 5-cm horseshoe magnet attached to an electric stirring motor. The large magnet was necessary to prevent the stirring bar from falling during the stirring.




FIG. 1. Apparatus for preparing dissolved oxygen standards.

8) The central chamber was opened to the water and the syringe. The oxygen was gently transferred to the bottle, where solution took place in approximately 10 min.

9) The apparatus was unclamped and the mercury allowed to run back and forth from the central chamber thoroughly to mix the solution, including the portion in the stopcock bore. The walls of the bottle were inspected with a hand lens and all visible mercury transferred back into the central chamber by scrubbing with a globule of mercury.

10) The stopcocks were rotated and the sample bottle removed from the apparatus. The excess water was allowed to spill, and the stopper was inserted in the bottle, thus isolating a known fraction of the added oxygen.

11) The fraction of the added oxygen contained in the bottle was determined by the technique for the Winkler method outlined above.

12) The mercury content of the final titrated solution was determined by spectrophotometric analysis based on measurement of the 320-m μ absorption peak of mercuric tetraiodide and at 350 m μ to correct for the trace turbidity of the solution. A 12.5-cm absorption cell permits the determination of 0.1 μ cg of mercury to 10%.

RESULTS

Table 2 shows the results for six preparations of oxygen standards. The oxygen was an Air Reduction Company research grade gas, with a stated maximum limit of possible impurities of 0.14%. Dr. Bruce Benson of Amherst College kindly analyzed the oxygen by mass spectrometry. The sum of

the nitrogen, argon, carbon dioxide, and water was found to be $0.10 \pm 0.03\%$.

The values for iodine found were based on standardization of the thiosulfate with iodine generated from biiodate. As noted above, comparison of assayed biiodate with certified iodate gave agreement to 0.04%. This suggests that the uncertainty in determining iodine was not greater than 0.04%, since the precision of the weight photometric titration for these quantities of iodine was 0.01%. The accuracy evaluation attempted here is a comparison based on the above compositions of the oxygen and of the iodine standards. An observed difference might be ascribed to an error in the indicated compositions, nonstoichiometric behavior in the Winkler reaction sequence, or unknown errors produced in the manipulations.

It was fortunate that the final solution from the Winkler analysis was precisely the composition suitable for the simple photometric mercury analysis. The sources of the mercury were solution of the elemental mercury in the water (solubility 60 μ g/liter), minute particles adhering to the sample bottle, and possibly the reaction of the mercury with the dissolved oxygen during the solution process. While the corrections for mercury contamination are significant, an uncertainty of not more than 0.02% resulted from this source.

The oxygen content of the reagents was found from the addition of various amounts of the reagents to water scrubbed with nitrogen to produce a low oxygen concentration and also by addition to water degassed by boiling under vacuum. An uncertainty of not more than 0.02% resulted from this source.

In view of the several uncertainties, particularly in the gas composition, and the variance of the results, the small value for the mean of the differences (+ 0.002%) in Table 2 is clearly accidental. The variance appears to be produced mainly from the gas volume measurements. The barometric pressure readings had a variance of approximately 0.03%, and the stopcock system requires the use of grease that may ac-

TABLE 2. Results of titration of oxygen standards

Oxygen taken (meq)	Iodine found (meq)	Mercury found (meq)	Oxygen in reagents (meq)	Apparent oxygen (meq)	Difference (%)
0.6016	0.6018	0.0012	0.0012	0.6018	+0.03
0.5983	0.5990	0.0009	0.0012	0.5987	+0.07
0.6120	0.6131	0.0002	0.0012	0.6121	+0.01
0.6162	0.6176	0.0006	0.0012	0.6170	+0.13
0.6188	0.6184	0.0010	0.0012	0.6182	-0.10
0.6167	0.6168	0.0003	0.0012	0.6159	-0.13

accumulate and then be removed to produce volume changes of approximately 0.05%. The effect of these factors could be reduced by redesign of the system, but an accuracy of better than 0.1% does not appear to serve any useful purpose. The high (0.02%) precision of the weight photometric titration does have an advantage for such purposes as measurements of solubility as a function of temperature and salinity, in which unknown functional dependence must be developed from a limited number of measurements.

CONCLUSIONS

Since the recovery of oxygen was quantitative to the expected accuracy of the prepared standards (0.1%), it is reasonable to conclude that the Winkler method as outlined here has an accuracy of 0.1%. Comparison of this technique with several other commonly used techniques shows differences of up to 5%, and it is inferred that errors of this magnitude result from inadequacies of the other techniques. An adaptation of the present technique for routine analyses will be described in another paper.

REFERENCES

- BRADBURY, J. H., AND A. N. HAMBLY. 1952. An investigation of errors in the amperometric and starch indicator methods for the titration of millinormal solutions of iodine and thio-sulfate. *Australian J. Sci. Res. Ser. A*, **5**: 541-554.
- KLOTS, C. E., AND B. B. BENSON. 1963. Solubilities of nitrogen, oxygen and argon in distilled water. *J. Marine Res.*, **21**: 48-57.
- KNOWLES, G., AND G. F. LOWDEN. 1953. Methods for detecting the end point in the titration of iodine with thiosulphate. *Analyst*, **78**: 159-164.
- MORTIMER, C. H. 1956. The oxygen content of air-saturated fresh waters, and aids in calculating percentage saturation. *Intern. Assoc. Theoret. Appl. Limnol. Commun.* No. 6.
- RICHARDS, F. A., AND N. CORWIN. 1956. Some oceanographic applications of recent determinations of the solubility of oxygen in sea water. *Limnol. Oceanog.*, **1**: 263-267.
- TRUESDALE, C. A., A. L. DOWNING, AND G. F. LOWDEN. 1955. The solubility of oxygen in pure water and sea-water. *J. Appl. Chem. London*, **5**: 53-62.
- WHEATLAND, A. B., AND L. J. SMITH. 1955. Gasometric determination of dissolved oxygen in pure and saline water as a check of titrimetric methods. *J. Appl. Chem. London*, **5**: 144-148.
- WINKLER, L. W. 1888. Die Bestimmung des im Wasser gelösten Sauerstoffes. *Chem. Ber.*, **21**: 2843-2855.

NOTES AND COMMENT

THE CHESAPEAKE BAY INSTITUTE TECHNIQUE FOR THE WINKLER DISSOLVED OXYGEN METHOD

A modified technique for the Winkler determination of dissolved oxygen has been used at the Chesapeake Bay Institute for several years. The modifications result in increased simplicity and speed and reduction in the errors due to manipulation. The unusual features of the technique are the elimination of the volumetric transfer of the final iodine solution and the reagent concentrations.

The sources of errors in the various techniques for the Winkler method are discussed in detail by Carpenter (1965) and by Carritt (1964), who also reports the results of an intercomparison experiment.

APPARATUS

Sample flasks—Erlenmeyer flasks of 125-ml nominal capacity (130–140 ml calibrated capacity) with full-length 19/38 ground-glass stoppers are used. Bottles may be substituted for the flasks, but more care is required to avoid trapping air bubbles. The stoppers should be rounded or tapered to avoid trapping air bubbles.

Reagent dispensers—Syringes with Chaney adapters are used for the viscous reagent solutions. Any rapid delivery automatic pipette may be substituted.

Microburette—A 1-ml total capacity burette is required. The most satisfactory burette appears to be the Gilmont micro-pipette-burette (Emil Greiner Co.) with digital counter readout. Filling the burette can be facilitated by attaching it to a capillary three-way stopcock that has a 100-ml reservoir and the delivery tip on its other two arms. The burette is mounted in a three-sided box with a white interior (Fig. 1). Lights and a magnetic stirrer are mounted in the box. Two 8-w fluorescent lamps, located at the forward vertical edges, give adequate illumination. The magnetic stirrer is mounted so that it can be swiveled

in the horizontal plane to permit positioning the sample flask under the burette with the delivery tip immersed in the sample. The pipettes for standardization and blank determination are hung on the wall of the box for convenience.

REAGENT SOLUTIONS

1) $MnCl_2 \cdot 4H_2O$	600 g/liter (3 M)
2) NaOH	320 g/liter (8 N)
NaI	600 g/liter (4 M)
3) H_2SO_4	280 ml concd H_2SO_4 /liter (10 N)
4) Starch	1% solution
5) $Na_2S_2O_3 \cdot H_2O$	35 g/liter (0.14 N)
6) KIO_3	0.3567 g/liter (0.01 N)

NOTES

1) Manganous sulfate may be substituted for the chloride. The chloride is suggested because of its solubility and its freedom from higher-valence manganese com-




FIG. 1. Titration apparatus.

pounds in the commercial products examined.

2) The sodium hydroxide-sodium iodide reagent has the desirable features of the Pomeroy-Kirschman reagent without its excessive viscosity and tendency to crystallize. The hydroxide is adequate to precipitate all the manganese and to react with a bicarbonate alkalinity of 2×10^{-3} N (sea-water). The sodium iodide is sufficiently concentrated to decrease the amount of free iodine to 5% of the total iodine in air-saturated water samples. This increased complexing of iodine as the triiodide ion results in sharper end points and reduces volatilization losses. The oxygen content of the manganous chloride and the sodium hydroxide-sodium iodide solutions amounts to the addition of 0.018 ml/liter when 1 ml of each reagent is used in a 140-ml sample.

3) The strength of the sulfuric acid reagent is chosen so that the final solution will be pH 2. Greater acidity favors the air oxidation of iodide ions. The final pH must be less than 2.7 for the solution and reaction of the oxidized manganese. The errors in the volumes of the hydroxide and acid solutions should not be greater than 5% for proper pH control.

4) A variety of stable starch solutions has been proposed in the literature, but freshwater solutions are satisfactory and easily prepared. The starch should be discarded when any reddish tint of the starch-iodine complex is noted.

5) The 0.14 N sodium thiosulfate solution should be used for samples with a maximum dissolved oxygen concentration of 5.5 ml/liter. For more concentrated samples, the strength of the thiosulfate solution should be increased to avoid refilling the burette during titration.

6) While potassium iodate is suggested here, potassium biiodate appears to be an equally good iodine standard. The virtue of the iodate is its stability during drying (180C). Decomposition of the biiodate at temperatures above 100C can be observed, and it should be dried by vacuum desiccation. Potassium dichromate is not a satisfactory standard because it is impractical

to avoid air oxidation of iodide at the high acidities required for the reaction between dichromate and iodide ions.

PROCEDURE FOR SAMPLES

1) Collect the desired number of replicate samples in 125-ml glass-stopper Erlenmeyer flasks that have been calibrated "to contain" by weighing. Flasks having calibrated volumes of from 130 to 140 ml are suitable, and no effort should be made to pair flasks of equal volume. Fill and overflow by at least one bottle volume.

2) Add 1 ml of the manganous ion solution and 1 ml of the sodium iodide-sodium hydroxide solution with a syringe or other rapid delivery pipette and seat the stopper securely without trapping bubbles.

3) Disperse the precipitate uniformly throughout the bottle by shaking. Allow the precipitate to settle at least halfway to the bottom and repeat the shaking. Allow the precipitate to settle two-thirds of the way to the bottom.

4) Add 1.0 ml of the sulfuric acid, stopper, and mix thoroughly.

5) Place a magnetic stirring bar in the flask. Titrate with 0.14 N sodium thiosulfate from the microburette to a straw yellow color, add 0.5 ml of starch indicator solution and continue the titration to the complete disappearance of the blue complex.

STANDARDIZATION

Pipette 10 ml of 0.01 N potassium iodate into a clean sample flask and nearly fill with distilled water. Add 1.0 ml of the sulfuric acid reagent and 1 ml of the sodium iodide-sodium hydroxide reagent. Titrate the liberated iodine as for the sample. The sample flask must be carefully rinsed to avoid the presence of manganese ions, or a separate flask should be reserved for the standardization.

BLANK DETERMINATION

Pipette 1 ml of 0.01 N potassium iodate into a *clean* sample flask and nearly fill the flask with distilled water. Add 1.0 ml of

the sulfuric acid reagent, 1 ml of the sodium iodide-sodium hydroxide reagent, mix, and then add 1 ml of the manganous ion reagent. Titrate precisely to the end point.

Pipette a second 1 ml of 0.01 N potassium iodate into the final solution above. Titrate the liberated iodine.

The difference between the first and second titrations is the reagent and indicator blank. Manganese must be absent during the hydroxide addition.

The procedure may be repeated using sample water rather than distilled water to determine the blank due to sample constituents that liberate or react with iodine in acid solution. The method is unsuitable for grossly polluted samples.

Either positive or negative blanks may be found for the reagents.

CALCULATION OF RESULTS

The concentration of dissolved oxygen in the sample may be computed from the following equation:

$$DO = \frac{(R - R_{\text{blk}})V_{10_3} \cdot N_{10_3} \cdot E}{(R_{\text{std}} - R_{\text{blk}})(V_b - V_{\text{reg}})} - DO_{\text{reg}}$$

where

DO = dissolved oxygen (ml/liter)

R = sample titration burette reading

R_{blk} = difference between blank titrations burette readings

R_{std} = standardization burette reading

V_{10_3} = volume of KIO_3 standard (ml)

V_b = volume of sample bottle (ml)

V_{reg} = volume of sample displaced by reagents (ml)

N_{10_3} = normality of KIO_3 standard (equivalent/liter)

E = 5,598 ml O_2 /equivalent, and

DO_{reg} = oxygen added with reagents

For the procedure described,

$$DO = \frac{(R - R_{\text{blk}})559.8}{(R_{\text{std}} - R_{\text{blk}})(V_b - 2)} - 0.018$$

GENERAL COMMENTS

Titration of the whole sample has the following features:

1) Speed. Elimination of removing aliquots expedites the titration.

2) Precision estimate. Titration of duplicate aliquots safeguards against gross titration errors and permits the estimation of the precision of the aliquoting and titrating. However, the precision of the method must be based on repetition of the whole procedure. The normal variation in bottle size results in different titers for replicates, which eliminates the personal tendency to obtain the same result for aliquots.

3) Minimum volatilization error. Transfer of aliquots by graduated cylinder results in greater losses of iodine than does pipette transfer, suggesting that the common procedure of transfer of the whole sample to a titration vessel also results in serious iodine loss.

4) Convenience. The digital readout burette and absence of the transfer step make precise results possible even under adverse conditions.

5) Cost. The full-length ground-glass stoppers and flasks used are approximately twice as expensive as standard medium-stopper bottles. The burette used is from three to six times as expensive as an ordinary burette, but the cost of the glass parts is comparable to that of an ordinary burette.

6) Calculation. The volume of each bottle and stopper combination enters the calculation of the results, so a factor converting the burette to dissolved oxygen concentration cannot be used.

JAMES H. CARPENTER

*Chesapeake Bay Institute,
The Johns Hopkins University,
Baltimore, Maryland.*

REFERENCES

- CARPENTER, J. H. 1965. The accuracy of the Winkler method for dissolved oxygen. *Limnol. Oceanog.*, **10**: 135-140.
- CARRITT, D. E. 1964. Intercomparison of methods in chemical oceanography. I. Precision and accuracy of the Winkler method. National Academy of Sciences-National Research Council. (In press.)

Dissolved Oxygen Sewage Sampler (Phipps & Bird)



Our Dissolved Oxygen Sewage Sampler collects two simultaneous samples in accordance with APHA specifications. A bucket-type sampler, it's perfect for manual spot-sampling of water or wastewater at depths up to five feet. *Catalog number 8392-001.*

- Displaces three times bottle volume without aeration.
- Collects samples suitable for BOD, DO, and other laboratory determinations.
- Accommodates two 250- or 300-mL bottles.
- Easily lowered to desired depth, since adequate weight is provided by stainless steel and nickel-coated brass construction.
- Comes with two sturdy suspension chains and rubber stoppers.
- Thermometer clip on air vent tube.
- Rubber gasket and clamps ensure airtight closure.

LaMotte® Dissolved Oxygen Sampler

Ingenious Design Ensures a Representative Sample



Just lower the clear, acrylic water sampler containing the 60 mL dissolved oxygen bottle to the desired depth. Water fills the bottle and overflows six times, ensuring an accurate, representative sample.

The filled bottle can then be used to run a dissolved oxygen test, while the remaining water in the outer chambers of the sampler can be used for any other type of test you need.

A nylon cord harness can attach to the calibrated line and is available separately. It comes with a water sampler, dissolved oxygen bottle, and sounding lead.

Size of sampler: 3 1/2" square x 6 1/2"H.

Item #	Description	Price	Qty
21 V 1063	LaMotte® Dissolved Oxygen Sampler	\$115.00	<input type="text"/>

(from "Standard Methods",
19th Edition, 1995)




Figure 4500-O:1. DO and BOD sampler assembly.